

Cleat Edge Rollformer

Forms Alternating Cleats down one edge of the pre-notched blank. Simple selector switch allows the operator to choose a leading or trailing form option.



