

# ELITE 110/65 TON



### FLEXIBILITY

- **Five Workstations:**
  - **Standard (4)** — Punch, Flat Bar Shear, Angle Shear & Coper Notcher
  - **Open (1)** — Customize your Ironworker with optional Attachments
- 12 interchangeable Attachments available to tailor the Ironworker to your needs
- 14 optional Accessories available to increase precision and efficiency



### PRODUCTIVITY

- Standard PowerLink™ System increases your capabilities by turning your Ironworker into a power source for our ever expanding line of Hydraulic Tools
- Compact machine that allows for fast and easy transitions between fabrication operations: punch, shear, notch, bend and cope all in one machine
- Two independent power plants produce true Dual Operation
- Hydraulic Hold Down automatically secures your material in place preventing movement for quick and clean shearing on both Flat Bar & Angle Shears

### SAFETY


- Adjustable electric stoke control
- Bright LED lights increase visibility
- ANSI B11.5-1988(02) Compliant Guarding
- ETL Certified Controls
- Integrated Lock-out/Tag-out system with multiple location E-Stops for added safety

### PERFORMANCE

- Durable, heavy-duty Made In USA steel construction
- Vertical movement produces even pressure resulting in precise punching and shearing with minimal distortion that results in extended tooling life
- Central Lubrication System simplifies Ironworker maintenance

STOCK #	PRODUCT DESCRIPTION
ELT11065-1P230	110/65 Ton Elite Dual Operator Ironworker 1 Ph, 230 V
ELT11065-3P208	110/65 Ton Elite Dual Operator Ironworker 3 Ph, 208 V
ELT11065-3P230	110/65 Ton Elite Dual Operator Ironworker 3 Ph, 230 V
ELT11065-3P380	110/65 Ton Elite Dual Operator Ironworker Int'l - 3 Phase, 380 Volt, 50 Hz
ELT11065-3P460	110/65 Ton Elite Dual Operator Ironworker 3 Phase, 460 V
ELT11065-3P575	110/65 Ton Elite Dual Operator Ironworker 3 P, 575 V

SPECIFICATIONS	
Punch Rating (tons)	110/65
Punch Max Capacity (in.)	1-3/8 diam. in 1 mild steel
Punch Work Height (in.)	37-1/2
Punch Throat Depth (in.)	17-3/4
Punch Stroke (in.)	3
Flat Bar Shear Max Capacity (in.)	3/8 x 24 1/2 x 14 1 x 4
Flat Bar Shear Work Height (in.)	33-1/2
Flat Bar Shear Max Round Capacity (in.)	1 diam.
Flat Bar Shear Max Square Capacity (in.)	1
Angle Shear Max Capacity (in.)	5 x 5 x 3/8
Angle Shear Work Height (in.)	44
Coper Notcher Max Capacity (in.)	2-1/2 x 6 x 3/8
Coper Notcher Work Height (in.)	35-5/8
Open Cavity Height (in.)	9
Open Cavity Width (in.)	11-3/4
Open Cavity Work Height (in.)	40-7/8
Standard Motor	7.5 HP
Amps	36
Hydraulics (GPM)	10-1/2
Hydraulics (PSI)	3000
Hydraulic Reservoir (gal.)	17
Product Dimensions (In.)	44-7/8 x 97 x 65-1/8
Shipping Dimensions (In.)	48 x 96 x 72
Weight (lbs.)	8,680



**STANDARD POWERLINK™ SYSTEM INCREASES YOUR CAPABILITIES BY TURNING YOUR IRONWORKER INTO A POWER SOURCE FOR OUR EVER EXPANDING LINE OF HYDRAULIC TOOLS**

- Simply PLUG IN & POWER UP any of our Hydraulic Tools and expand your fabrication capabilities
- Our factory installed PowerLink System includes quick connect couplings allowing easy transitions between Hydraulic Tools
- The EDWARDS Portable Power Unit is an additional power source with the PowerLink System



TURN THE PAGE TO VIEW OUR FULL LINE OF ATTACHMENTS & ACCESSORIES FOR THE ELITE 110/65 TON IRONWORKER



# ELITE 110/65 TON ATTACHMENTS

# ELITE 110/65 TON ACCESSORIES



### OVERSIZE PUNCH ASSEMBLY

- Accommodates punch & die sets in various shapes and sizes from 1" up to 1-9/16"
- Replaces Standard Punch Assembly or can be used as a secondary Punch Workstation

AC1024\*



### 241 PUNCH ASSEMBLY

- Accommodates punch & die sets in various shapes and sizes from 1" up to 4"
- Punch large holes and slots in anything from heavy sheet metal to steel beams

AC1055-6\*



### ANGLE NOTCHER

- Take precise 92° notch out of mild steel up to 3" x 3" x 1/4"
- Allows for an easy 90° to create a steel frame

AC1025\*



### PIPE NOTCHER HOUSING

- Make clean 90° saddle joint connections quickly and easily
- Compatible with all Edwards Ironworkers
- Contact Edwards for custom dies to match your project
- Pipe Notcher Dies sold separately

AC0925\*



### PIPE NOTCHER HOUSING FOR OPEN CAVITY

- Make clean 90° saddle joint connections quickly and easily
- Compatible with the 65,120, and 110/65 Ton Elite Ironworkers
- Contact Edwards for custom dies to match your project
- Pipe Notcher Dies sold separately

AC0925C\*\*



### TURRET PIPE NOTCHER

- Make clean 90° saddle joint connections quickly and easily
- Compatible with all Edwards Ironworkers
- Contact Edwards for custom dies to match your project
- Pipe Notcher Dies sold separately

AC0925T\*



### MULTI SHEAR

- Designed to shear flat bar up to 1/4" x 6" and angle iron up to 2" x 2" x 1/4"
- Shears solid round bar 1/4", 3/8", 1/2", 3/4" and 13/16" square bar

AC1075\*



### ROD SHEAR

- Shear solid round rod easily with the Rod Shear
- Handles 1/4", 3/8", 1/2", 5/8", 3/4" and 1" solid round bar

AC1074\*



### BRAKE WITH 4-WAY DIE

- Choose from the sizes listed below to meet your specific needs
- Fabricate brackets, frames, pans and tanks with this Brake with 4-Way Die
- Includes a standard punch that allows 1/16", 1/8", 3/16" and 1/4" material to be formed to a 90° angle

7"	8"	10"	10" OPEN CAVITY	12"
AC1033*	AC1034*	AC1051*	AC1052*	AC1035*



### HEAVY DUTY GAUGING TABLE KIT

- 1" x 12" x 16" table adds speed and precision to your Punch Workstation
- Replaces Standard Pedestal Die Table
- Adjustable fences and handles quickly and easily guide your material for perfect repeatable actions

AC0903



### HEAVY DUTY GAUGING TABLE KIT FOR OVERSIZED PUNCH ASSEMBLY

- 1" x 12" x 16" table adds speed and precision to your Punch Workstation
- Replaces installed Die Table
- Adjustable fences and handles quickly and easily guide your material for perfect repeatable actions

AC0905



### URETHANE STRIPPER

- Minimize material distortion when working with light gauge material

AC1099



### QUICK CHANGE PUNCH ASSEMBLY

- Accommodates punch and increase your efficiency by saving time and money with the Quick Change Punch Assembly.
- Accepts both Standard and Oversize Punch & Die Sets

AC1001



### AUTO CUT - 48"

- Optimize your productivity on both the Flat Bar Shear and Angle Shear Workstations on your Edwards Ironworker
- The adjustable proximity sensor automatically cycles your Ironworker as you feed in material

AC1010



### BACK GAUGE - 48"

- Speed up production on repeatable cuts by providing an adjustable stop for the Flat Bar Shear and Angle Shear
- A positive stop attachment that is fitted to the back of the Ironworker ensures accurate shearing

AC1011



### PRESS BRAKE BACK GAUGE

- Speed up production on repeatable bends by providing an adjustable stop for the various size Brake Attachments
- A positive stop attachment that is fitted to the back of the Ironworker ensures accurate bending

PR135



### PUNCH & DIE STARTER SET

- Includes 8 standard round punch & die sets selected to accommodate the most commonly used bolts
- Sized in 1/8" increments from 3/16" to 1-1/16" with 1/32" clearance
- See catalog page 68-71 for additional Punch & Die Sets

PD1000



### ACCESSORY LIGHT

- Super bright LED light with M12 connections plugs
- Powerful magnetic base allows users to attach the light to any Ironworker surface and move as needed

AC1000



### FABRICATOR'S PROTRACTOR

- Increase user accuracy on the Punch and Flat Bar Shear Workstations
- Designed to guide your workpiece and gauged at 15° increments through 180°

AC1017



### 12" & 18" FENCES GUIDES

- Easily adjustable to align your material, these 12" or 18" fence guides make precise, repeatable operations simple.

AC1910 12" Standard Handles  
AC1911 18" Standard Handles  
AC1912 12" Heavy Duty Handles  
AC1913 18" Heavy Duty Handles

\*IMAGE NOTE: Guarding removed for clarity

\*IMAGE NOTE: Guarding removed for clarity

